



floating tenon corner joint option  
double #20 biscuit corner joint option

End Frame and Panel Assembly

Frame and Panel Door Assembly

NOTE: Extend the back edges of the back stiles 1/4" to 1/2" beyond the back panel to allow for scribing the cabinet to fit the wall